KitchenAid®

COOKTOP PARTS

For Model: KERC507YWH2, KERC507YAL2
(White) (Almond)

30" ELECTRONIC RANGE
FREESTANDING
DESIGNER STYLE
SELF−CLEAN OVEN
CERAMIC COOKTOP



Illus. No.	Part No.	DESCRIPTION
		NOTE: The screws and nuts required to attach a part are listed immediately following that part.
1		Cooktop, Ceran
	9780853	White Mdl.
	9781060	Almond Mdl.
2		Gasket, Cooktop
	9780939	Front & Sides
3	9780742	Rear Gasket
4		Frame, Cooktop
	4211918	White
	4211919	Almond
	3149333	Screw, (4) 10AB x 1/2
5	9750455	Support, Element
6		Back Splash
	4211921	White
	4211922	Almond
	3149333	Screw (4) 10AB x 1/2"
7	422404	Brace, Support
	9780273	Screw (2) 10 x 3/4"
8	9750821	Support Clips (4)
	423248	Screw, (4) 10 x 3/4"
9	9750969	Bumper (4)
10	9780931	Hot Light
		Element, Surface
11	9750752	6", LR
12	9750755	9", LF
13	9750754	8", RR
14	9750753	7", RF
15	9780679	Spring (12)
16		Limiter, Temp.
	3149129	6", LR
	3149124	9", LF
	3149123	8", RR
	3183972	7", RF
17	915720	Screw, Anchor

LITERATURE PARTS

LIT9780936	Use And Care Guide
LIT9780689	Quick Set Instr. (Timer)
LIT3150693	Cookbook, T/C Ovens
LIT9750876	Wiring Diagram
LIT3183987	Guide−Auto Set
LIT9780945	Label, Instruction (Lamp Cover)
LIT3183790	Video, Cooking
LIT9750520	Installation Inst.
LIT9750877	Tech Sheet

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CONTROL PANEL PARTS

For Model: KERC507YWH2, KERC507YAL2
(White) (Almond)



Illus. No.	Part No.	DESCRIPTION
		NOTE: The screws and nuts required to attach a part are listed immediately following that part.
1		Lamp Cover
	9780580	White
	9780581	Almond
2	422581	Light, Fluorescent
3		Lamp Cover Insert
	9780295	White
	9780332	Almond
4		End Cap R.H.
	4211934	White
	4211933	Almond
	9780265	Screw, (2) 10 x 3/8
5		End Cap L.H.
	4211937	White
	4211936	Almond
	9780265	Screw, (2) 10 x 3/8
6		Panel, Control
	9780293	White
	9780329	Almond
	9780852	Screw, (2) 8 x 3/8
8		Knobs, Control
	4211909	White (4)
	4211913	Almond (4)
10	9750343	Indicator Lens
11	9750964	Light Module (4)
12	9750866	Starter Holder
13	9750273	Receptacle, Light
15		Oven Control Assembly
	9750700	White
	9750699	Almond
16	9780655	Brace, Control Pnl
17		Button, Light
	4212112	White
	4212113	Almond
18	9751110	Switch, Light
21	9750721	Bracket, Switch
22	9781118	Starter, Lamp
23	9750639	Infinite Switch, 1700W, LR−RF
24	9750641	Infinite Switch, 2400W, LF−RR
	9780268	Screw (8) 8−32 x 3/16

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

DOOR AND DRAWER PARTS

For Model: KERC507YWH2, KERC507YAL2
(White) (Almond)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

DOOR AND DRAWER PARTS

For Model: KERC507YWH2, KERC507YAL2
(White) (Almond)

Illus. No.	Part No.	DESCRIPTION
		NOTE: The screws and nuts required to attach a part are listed immediately following that part.
2		Trim, Door−Left
	4211912	White
	4211914	Almond
3		Trim, Door−Right
	4211910	White
	4211911	Almond
4		Trim, Door Bottom
	4211925	White
	4211926	Almond
	9780265	Screw, 10 x 3/8
5		Glass, Door
	9780314	White
	9780328	Almond
6		Vent, Door
	4211907	White
	4211908	Almond
	3149333	Screw (2) 10AB x 1/2
7	9750898	Vent Back
8		Handle, Door
	4212234	White Mdl.
	4212235	Almond Mdl.
	9781072	Screw (4) 10 x 1/2 (2)
9	9750694	Gasket, Door Glass
10	9750234	Hinge, Door R or L
	9780265	Screw (4) 10 x 3/8
11	9750693	Heat Channel
	9780265	Screw (2) 10 x 3/8
12	9750634	Baffle, Glass
13	4211941	Shield Door
14	9780771	Bumper, Rubber
15	9751245	Window Pack (Assembly)
16	9751135	Seal, Window
18	9750231	Insulation
19	4212163	Liner, Door
20	9750257	Drawer & Roller
21	9750169	Bracket, Drawer
	9780272	Screw (4) 10 x 1/2
22		Trim,Drawer Bottm.
	4211905	White
	4211906	Almond
	9780265	Screw, (3) 10 x 3/8
23		Trim, Drawer Top
	4211931	White
	4211932	Almond
	9780265	Screw, (2) 10 x 3/8
24		Front, Drawer
	4211916	White
	4211917	Almond
25		Glass, Drawer Face
	9750612	White
	9780326	Almond
26	9751248	Latch, Drawer
	9780806	Screw 4AB x 3/8
27	814229	Roller, Support(2)

OVEN CHASSIS PARTS

For Model: KERC507YWH2, KERC507YAL2
(White) (Almond)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

OVEN CHASSIS PARTS

For Model: KERC507YWH2, KERC507YAL2
(White) (Almond)

Illus. No.	Part No.	DESCRIPTION
		NOTE: The screws and nuts required to attach a part are listed immediately following that part.
1	9750146	Main Chassis, Back
2	4211893	Chassis, Front
3	9750222	Insulation, Wrap
4	9750221	Insulation, Rear
5	4211892	Oven Liner
6	9750247	Gasket Oven
7		Oven , Side L or R
	4211896	White
	4211897	Almond
	9780265	Screw (4) 10 x 3/8
8	9780664	Shield, Insulation
	9780265	Screw (2)
10	9780585	Wire Guard
	9780930	Screw, (2) 8−18 x 1/2
	9780265	Screw, (2) 10 x 3/8
11	9750478	Burner Box
	9780265	Screw (7) 10 x 3/8
	9780275	Screw, (2) 8 x 3/8
12	9750142	Oven Bottom
	9780265	Screw (9) 10 x 3/8
15	9750223	Drawer Rail, Left
	9750224	Drawer Rail, Right
	9780265	Screw (2) 10 x 3/8
17	9750147	Bottom Rail (2)
	9780265	Screw, (8) 10 x 3/8
18	312701	Foot, (4)
19	9750149	Hinge, Base L or R
	9780265	Screw, (2) 10 x 3/8
	9780270	Screw, (2) 8 x 3/8
20	421771	Support Rail, Pan
	9780265	Screw, (2) 10 x 3/8
22	9750258	Hinge, Cktp.−Left
	9750416	Hinge, Cktp.−Right
	9780265	Screw, (4) 10 x 3/8
23	9750491	Bracket, P−Cord
	9780272	Screw, (2)
25	9750736	Vent Tube
26	9750393	Cover, Vent
27	9750394	Back, Vent
	9780265	Screw, (1) 10 x 3/8
28	9750897	Switch, Door−Light
29	9750767	Vent Gasket

Following Parts Not Illustrated

	814167	Anti−Tip Kit
	3184477	Glass Cleaner
	3183488	Scrapper, Glass

OVEN PARTS

For Model: KERC507YWH2, KERC507YAL2
(White) (Almond)



Illus. No.	Part No.	DESCRIPTION
		NOTE: The screws and nuts required to attach a part are listed immediately following that part.
1	9750967	Element, Broil
2	9750213	Element, Bake
3	9751447	Element, Convection
	9780269	Screw, Elements 8−32 x 3/8
4	4173237	Nut
5	9751117	Fan
6	4173238	Shim Ring
8	9751118	Assembly, Fan
	9781073	Screw, 10 x 1/2
9	4211894	Baffle, Convection
	9780270	Screw, (2) 8 x 3/8
10	4167277	Lock−Nut, Cvr.Jack
11	4167266	Jack Cover
12	4163975	Gasket
13	4173575	Receptacle, Probe
14	3179672	Spacer, Tubing
15	4211947	Bulb, Oven
16	9781050	Socket, Light
17	3150144	Probe
18	4421424	Grill, Broiler
19	4211944	Pan, Broiler
20	3181534	Rack, Roasting
21	9750823	Rack, Standard
22	3148440	Sensor
	9780269	Screw, (1) 8−32 x 3/8
23	9781049	Len's Light
24	3184533	Gasket, Len's

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

WIRING HARNESS PARTS

For Model: KERC507YWH2, KERC507YAL2
(White) (Almond)



Illus. No.	Part No.	DESCRIPTION
1	9751151	Harness,Convection (Oven−Fused)
2	9751155	Harness, (Lock Switch)
3	9751111	Harness, (Cooktop)
4	9751148	Harness, (Control)
5	9750376	Harness, (Door)
6	9751139	Harness, (Probe)
7	422667	Harness Clip
8	9750984	Hanger, Cable
10	9751369	Harness, Lead (Fused)

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

REAR CHASSIS PARTS

For Model: KERC507YWH2, KERC507YAL2
(White) (Almond)



Illus. No.	Part No.	DESCRIPTION
2	9750490	Cover, Rear Access
	9780265	Screw
3	9750245	Rear Panel
	4211813	Screw, (2) 10 x 3/8
	4212071	Washer
5	9750526	Bracket, Lock
	9780265	Screw (2) 10 x 3/8

Illus. No.	Part No.	DESCRIPTION
6	9750522	Oven Lock Assembly
	9780265	Screw, (2) 10 x 3/8
8	9750524	Solenoid
	4211945	Screw, (2) 10−32 x 5/16
	4211875	Washer
12	9750965	Switch, Interlock
	9750887	Screw, (2)
	9750888	Nut (2)
13	9750834	Bracket, Spring

Illus. No.	Part No.	DESCRIPTION
14	9750833	Spring, Door Lock
	9780265	Screw (1), 10 x 3/8
15	9750523	Rod, Lock
16	9780881	Ballast, Lamp
	9780265	Screw (2) 10 x 3/8
	4211875	Washer
17	258076	Terminal Block
	112432	Nut,Terminal Block
18	308498	Ground Strap

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

OPTIONAL PARTS (NOT INCLUDED)

For Model: KERC507YWH2, KERC507YAL2
(White) (Almond)

Illus. No.	Part No.	DESCRIPTION
SPLICING WIRES−−25FT. LENGTH		
	242828	Wire, Black 12 Ga. 150°c
	242820	Wire, Black 14 Ga. 150°c
	242821	Wire, Blue 14 Ga. 150°c
	242822	Wire, Brown 14 Ga. 150°c
	242830	Wire, Brown 14 Ga. 200°c
	242823	Wire, Green 14 Ga. 150°c
	242824	Wire, Orange 14 Ga. 150°c
	242829	Wire, Red 12 Ga. 150°c
	242825	Wire, Red 14 Ga. 150°c
	242831	Wire, Red 14 Ga. 200°c
	242826	Wire, White 14 Ga. 150°c
	242827	Wire, Yellow 14 Ga. 150°c
	242832	Wire, Yellow 14 Ga. 200°c
PAINT, TOUCH−UP (1/2oz.)		
	72017	White
	72107	Almond
	72109	New Avocado
	72108	Coffee
	72110	Harvest Gold
	72112	Toast
	72113	Platinum
	**511873	White Porcelain (2 Oz.)
PAINT, PRESSURIZED SPRAY (13 oz.)		
	350930	White
	350956	Almond
	261888	New Avocado
	261886	Coffee
	261890	Harvest Gold
	285365	Toast
	285366	Platinum
	285006	Superior Black
	206922	Primer (White)
	206925	Leveler (Thinner) (2 Oz.)
PAINT, BULK (1 qt.)		
	799344	White (Uncut)
	978883	Almond (Uncut)
	261891	Harvest Gold (Uncut)
	285367	Toast (Uncut)
	285368	Platinum (Uncut)
REFINISHING MATERIAL		
	799832	Kit, Porcelain Repair (White)
	242756	Touch−Up Self−Clean (1/2 Pt.)
	261582	Grease
	814009	Glass Cleaner
INSULATION		
	261514	Insulation, Fiberglass (1−1/2" x 24" x 120")
	240132	Insulation, Fiberglass (2−1/2" x 22" x 120")
	241430	Foil, Aluminum Oven (18" x 25')

** Porcelain; All Other Panels are Painted Surfaces.